


Generator Self-test Verifier[®]

How it works when the generator auto-start self-test doesn't



Generator Self-test Verifier sounds an alarm and optionally signals the Central Monitoring Station through a phone line or wirelessly. If a problem is reported, the generator owner or the maintenance contact is notified with an alert that service may be needed.



Outside Test cycle is initiated

Inside GSV determines test is unsuccessful

Offsite Alarm is triggered